

# GREENTAPE

## Self-Adhesive Air/Vapour Barrier Tape

Self-adhesive air/vapour barrier tape for wall panels



### **A**dvantages

- Air and vapour barrier
- Made with 45% recycled matters
- Excellent adhesion to a variety of substrates such as concrete, plywood, gypsum board, etc.
- UV ray resistance for up to 30 days

lexcor.net

Visit our video channels: <https://vimeo.com/channels/lexcoren>

COMMERCIAL BUILDING PRODUCTS


Ontario & Western Canada  
1.800.268.2889



Quebec & Eastern Canada  
1.800.363.2307

# GREENTAPE

AIR AND VAPOUR  
BARRIER  
SELF-ADHESIVE TAPE



## TECHNICAL SPECIFICATIONS DIMENSIONS

Width: 6" (152.40 mm)      Length: 50' (15240 mm)  
9" (228.60 mm)  
12" (304.80 mm)  
18" (457.20 mm)  
36" (914.40 mm)

PERFORMANCE CHARACTERISTICS	
Tear resistance (ASTM D-2261-07a)	Length: 60 lbs, 2660 N Width: 60 lbs, 266 N
Puncture resistance (ASTM D4833-00)	141 lbs / 625 N
Hydraulic conductivity (permeability) (ASTM D4491-99a (2009))	$1 \times 10^{-7}$ cm/s
Dimensional stability (ASTM D1204-02)	Length: -3,2%, -3,5% Width: 60 lbs, 266 N
Accelerated resistance to UV rays (ASTM G151-00) (G154-04)	90% force retention after 2000 hres exposure @ 0,77 W/m <sup>2</sup> , or 1200 hres exposure @ 1,35 W/m <sup>2</sup>

### APPLICATIONS

1. Greentite AVB panel joints
2. Door and window contours

### INSTALLATION

1. Prime the surfaces with a water or solvent based primer in order to get a clean surface.  
On plastic foam, only use a water-based primer such as Fransyl's Premier Multigrip.
2. Let primer dry completely before applying GREENTAPE.
3. Apply GREENTAPE as soon as ambient air temperature has reached 4°C (40°F) or higher.
4. Unroll, cut and position membrane as needed.
5. Peel off 150 mm of protective backing.
6. Apply membrane on its support while unrolling silicone backing.
7. Use roller on membrane after it has been properly installed to eliminate any air bubble.

### RESTRICTIONS

1. Not designed for prolonged exposure to bad weather.
2. Protect as soon as possible.
3. Do not use on PVC and Vinyl joints or membranes.

#### COMMERCIAL BUILDING PRODUCTS

Ontario & Western Canada  
1.800.268.2889



Quebec & Eastern Canada  
1.800.363.2307